

Shirayuki Sakura

白雪桜



05-120-014
Shirayuki Sakura 19.6cm Round Plate
白雪桜 6.0皿
φ19.6×3cm・372g
Qty.24/48pcs
JPY 650



05-120-015
Shirayuki Sakura 22.7cm Round Plate
白雪桜 7.0皿
φ22.7×3.3cm・536g
Qty.18/36pcs
JPY 800



05-120-016
Shirayuki Sakura 25.6cm Round Plate
白雪桜 8.0皿
φ25.6×3.4cm・738g
Qty.4/24pcs
JPY 1300



05-120-061
Shirayuki Sakura 12.7cm Donburi Bowl
白雪桜 多用碗 小
φ12.7×7cm・346g
Qty.6/48pcs
JPY 600



05-120-083
Shirayuki Sakura 16.8cm Donburi Bowl
白雪桜 5.5多用井
φ16.8×8.8cm・576g
Qty.9/36pcs
JPY 800



05-120-085
Shirayuki Sakura 15.3cm Flat Bowl
白雪桜 4.8ボール
φ15.3×5.5cm・348g
Qty.12/48pcs
JPY 600



05-120-086
Shirayuki Sakura 17.3cm Flat Bowl
白雪桜 5.5ボール
φ17.3×6cm・496g
Qty.9/36pcs
JPY 800



05-120-087
Shirayuki Sakura 19.7cm Flat Bowl
白雪桜 6.5ボール
φ19.7×7.2cm・680g
Qty.6/24pcs
JPY 1200



05-120-077
Shirayuki Sakura 11.4cm Small Bowl
白雪桜 3.6小鉢
φ11.4×6cm・200g
Qty.12/72pcs
JPY 480



05-120-253
Shirayuki Sakura 13.3cm Rice Bowl
白雪桜 手引4.2反和弁
φ13.3×6.2cm・236g
Qty.12/72pcs
JPY 480



05-120-045
Shirayuki Sakura Tonsui Bowl
白雪桜 とんすい
12.8×12.2×4.5cm・162g
Qty.20/120pcs
JPY 350



05-120-183
Shirayuki Sakura 20.2cm Deep Plate
白雪桜 三ツ輪カレー皿
φ20.2×4cm・398g
Qty.20/40pcs
JPY 600



05-120-051
Shirayuki Sakura 22.8cm Deep Plate
白雪桜 三ツ輪7.5めん皿
φ22.8×5cm・574g
Qty.12/24pcs
JPY 800



05-120-039
Shirayuki Sakura 24.5cm Shallow Bowl
白雪桜 8.0盛鉢
φ24.5×8cm・874g
Qty.9/18pcs
JPY 1400



05-120-114
Shirayuki Sakura 21cm Ramen Bowl
白雪桜 6.8高台ラーメン井
φ21×8.5cm・734g
Qty.6/24pcs
JPY 1200



05-120-080
Shirayuki Sakura 19.5cm Soba Bowl
白雪桜 6.5そば井
φ19.5×8cm・542g
Qty.8/32pcs
JPY 700



05-120-031
Shirayuki Sakura 17.2cm Square Plate
白雪桜 手引正角5.5皿
17.2×17.2×2.8cm・348g
Qty.20/40pcs
JPY 800



05-120-020
Shirayuki Sakura 21.7cm Rectangle Plate
白雪桜 長角8.0皿
21.7×14.6×3.5cm・536g
Qty.15/30pcs
JPY 900



05-120-097
Shirayuki Sakura 33.6cm Rectangle Plate
白雪桜 手引尺一長皿
33.6×19.7×3.6cm・1038g
Qty.2/12pcs
JPY 2800



05-120-117
Shirayuki Sakura 8.8cm Sauce Dish
白雪桜 角チョコ
8.8×6.5×2.8cm・108g
Qty.15/120pcs
JPY 380