



Shirayuki Sakura

白雪桜



03-120-014
Shirayuki Sakura 19.6cm Round Plate
白雪桜 6.0皿
φ19.6×3cm・380g
Qty.24/48pcs
JPY 800



03-120-015
Shirayuki Sakura 22.7cm Round Plate
白雪桜 7.0皿
φ22.7×3.3cm・550g
Qty.18/36pcs
JPY 1000



03-120-016
Shirayuki Sakura 25.6cm Round Plate
白雪桜 8.0皿
φ25.6×3.4cm・750g
Qty.12/24pcs
JPY 1500



03-120-061
Shirayuki Sakura
12.7cm Donburi Bowl
白雪桜 多用碗 小
φ12.7×7cm・350g
Qty.6/48pcs
JPY 700



03-120-083
Shirayuki Sakura
16.8cm Donburi Bowl
白雪桜 5.5多用井
φ16.8×8.8cm・580g
Qty.9/36pcs
JPY 1100



03-120-085
Shirayuki Sakura 15.3cm Flat Bowl
白雪桜 4.8ボール
φ15.3×5.5cm・350g
Qty.12/48pcs
JPY 800



03-120-086
Shirayuki Sakura 17.3cm Flat Bowl
白雪桜 5.5ボール
φ17.3×6cm・500g
Qty.9/36pcs
JPY 1000



03-120-087
Shirayuki Sakura 19.7cm Flat Bowl
白雪桜 6.5ボール
φ19.7×7.2cm・680g
Qty.6/24pcs
JPY 1500



03-120-077
Shirayuki Sakura
11.4cm Small Bowl
白雪桜 3.6小鉢
φ11.4×6cm・200g
Qty.12/72pcs
JPY 650



03-120-253
Shirayuki Sakura
13.3cm Rice Bowl
白雪桜 手引4.2反和井
φ13.3×6.2cm・240g
Qty.12/72pcs
JPY 550



03-120-045
Shirayuki Sakura
Tonsui Bowl
白雪桜 とんすい
12.8×12.2×4.5cm・170g
Qty.20/120pcs
JPY 450



03-120-183
Shirayuki Sakura 20.2cm Deep Plate
白雪桜 三ツ輪カレー皿
φ20.2×4cm・400g
Qty.20/40pcs
JPY 750



03-120-051
Shirayuki Sakura 22.8cm Deep Plate
白雪桜 三ツ輪7.5めん皿
φ22.8×5cm・580g
Qty.12/24pcs
JPY 1000



03-120-039
Shirayuki Sakura 24.5cm Shallow Bowl
白雪桜 8.0盛鉢
φ24.5×8cm・880g
Qty.9/18pcs
JPY 1800



03-120-114
Shirayuki Sakura 21cm Ramen Bowl
白雪桜 6.8高台ラーメン井
φ21×8.5cm・750g
Qty.6/24pcs
JPY 1500



03-120-080
Shirayuki Sakura 19.5cm Soba Bowl
白雪桜 6.5そば井
φ19.5×8cm・550g
Qty.8/32pcs
JPY 1000



03-120-031
Shirayuki Sakura 17.2cm Square Plate
白雪桜 手引正角5.5皿
17.2×17.2×2.8cm・350g
Qty.20/40pcs
JPY 1000



03-120-020
Shirayuki Sakura 21.7cm Rectangle Plate
白雪桜 長角8.0皿
21.7×14.6×3.5cm・550g
Qty.15/30pcs
JPY 1100



03-120-097
Shirayuki Sakura 33.6cm Rectangle Plate
白雪桜 手引尺一長皿
33.6×19.7×3.6cm・1000g
Qty.2/12pcs
JPY 4000



03-120-117
Shirayuki Sakura
8.8cm Sauce Dish
白雪桜 角子ヨク
8.8×6.5×2.8cm・110g
Qty.15/120pcs
JPY 450